

Windows Turntable Controller

How do I install and use the free Windows Turntable Controller?

Step-by-step guide

Here are the steps:

1. Install the latest version of Visere Captura from the [Release Notes](#). Please make sure you install Version 2.0 or higher.
2. The turntable controller is in the same folder as the Visere Captura executable. Go to that folder.
3. [View the Mac version of this article](#) to learn more about the free Turntable Controller application that comes bundled with Visere Captura.

Related articles

- [Use Shutter Release](#)
- [Windows Turntable Controller](#)
- [Calibrate Turntables](#)
- [Turntable SDK Source Code](#)
- [Mac Turntable Controller](#)
- [Turntable Troubleshooting](#)